

# Advantage<sup>®</sup> 420 Half-Mask Respirator Donning Instructions



**1** Install cartridges by turning clockwise until stops are engaged.



**2** Open lever.



**3** Place cradle on head.



**4** Raise respirator to face.



**5** Close lever.



**6** Place neck straps behind head.



**7** Connect neck buckles, listen for click.



**8** Pull both straps evenly for comfortable fit.



**9** Perform fit check.

## Negative Pressure Seal Check:

Place your palms over cartridges lightly.\* Gently inhale so that the facepiece collapses slightly and hold breath for ten seconds. The facepiece will remain collapsed while the breath is held unless there is a leak in the seal. Adjust the straps for a comfortable and secure fit and repeat if necessary. The respirator must pass this seal check before the respirator is used.

*\* If using Splash Guard Filters, depress and hold the center portion of the filter so it collapses slightly forming a seal.*



*If using in non drop-down mode, thread the straps through the yoke as shown.*

**Before use, please read and familiarize yourself with the Advantage 420 Half-Mask Respirator Instruction Manual.**

Scan here to view manual:

